

**Free
Project
Idea!**



Super Mod Pendant

Glass quickly becomes a striking abstract design, inside a microwave!

Create unique handcrafted items to give or keep!

Super Mod Pendant

Designed by Jeanne Baruth for Diamond Tech

MATERIALS NEEDED

- 1 pc Fuseworks™ Transparent Green Sheet Glass
- Fuseworks™ Bits and Pieces
- Fuseworks™ Kiln Paper
- Fuseworks™ Microwave Kiln
- Fuseworks™ Glass Cutter
- Fuseworks™ Large Pendant Bail
- E6000® or other glass glue
- Fuseworks™ Safety Glasses

DIRECTIONS

Step 1

Measure and mark the following glass sheets:

Transparent Green – one 1 5/8" X 1 1/4"

6 pieces of small dichroic scraps small assorted sizes

Step 2

Using a glass cutter, cut glass to designated sizes as indicated above. Clean glass using paper towel moistened with water. Completely dry the surface of the glass with a lint free cloth.

Step 3

Next, cut a 2" X 2" piece of kiln paper. Remove the lid from the Fuseworks™ Kiln. Place the kiln paper on the kiln base.

Step 4

Layer the glass on the kiln paper. Start with the base, 1 5/8" X 1 1/4" green glass rectangle. Next, evenly space three dichroic bits in two rows on top of the green glass.

HOT TIP: Try using a different base glass such as white, black or clear.

Step 5

Carefully set the base with glass inside the microwave. Cover base and glass with kiln lid.

Step 6

Fuse using the chart below. PLEASE NOTE: All microwave and kiln combinations will have different firing patterns. Be sure to take careful notes and log all fusing times for future use. After time is up, open microwave and, using Hot Mitts, carefully lift the lid enough to inspect the fusing process. Add additional time in 30 second increments until desired results are achieved. Remove kiln from microwave using the Hot Mitts and place on a heat resistant surface. Cool the kiln at least 45 minutes with the lid on.

Removing the lid or peeking under the lid during this cooling stage will result in your project cracking. Glass remains hot for a long time and should be handled with great caution.

Step 7

When cool, adhere a large gold bail to the back of the pendant using a glass adhesive such as E6000®. Allow to dry according to glue manufacturer direction. Slip pendant onto your favorite chain and enjoy.

CAUTION

- Wear safety goggles when using glass crafting tools

1200 WATT MICROWAVE	
POWER	TIME
70%	2 Minutes, 30 Seconds
100%	1 Minute