

# PUMPKIN SUNCATCHER



## Instructions:

1. Cut glass following provided pattern.
2. Wrap all edges in copper foil tape and burnish.
3. Solder pumpkin including stem on the front and back sides.
4. Tin edges of leaves.
5. Add pre tinned curly wire as shown and solder it into existing solder seams.
6. Position leaves and solder onto wire.
7. Use flux remover to clean your piece followed by soap and water. Dry thoroughly.
8. Patina and polish as desired.

**Design Tip:**

Polishing your piece will protect your solder from oxidation.

# Pumpkin Suncatcher Pattern

