

TC-60

Circle Supercutter®

The Circle Supercutter features a vacuum cup for a positive grip on the glass surface.

The cutting unit is positioned on a pivoting radius bar which is ruled for precise adjustment. The blade swivels to align the wheel for left- or right-hand scores and utilizes an automatic lubrication system activated when pressure is applied to the head.

The blade has a replaceable wheel and axle. To remove the wheel, use a small screwdriver to unscrew and remove the axle.

Lubrication

While scoring, the oil fill cap should be opened 1/2 turn to improve oil flow. For lubrication, it is recommended to use a very light oil such as kerosene or a synthetic lubricant such as GAI Cutting Oil. As with all self-oiling cutters, the first use requires priming the oil system by depressing the cutting head several times until oil reaches the wheel.

